



AD-2124 Conducted EMI Plot:

Upper Trace is combined live (L1) and neutral (N) Peak Measurement.
Lower Trace is combined live (L1) and neutral (N) Average Measurement.